

INSTALLATION OF NAL TEMPORARY FOUNDATIONS

1. Position temporary foundation on a level and stable surface.
2. Remove pedestrian cover and side chamber lid on Retention Socket.
3. Connect duct to one of the duct entry points.
3. Attach appropriate lifting/moving equipment to existing traffic signal pole.
4. Cut existing traffic signal pole close to ground level.
5. Pull new cable through one of the duct entry points and up through retention socket head.
6. Position pole close to temporary foundation and joint cables together.
7. Lift pole into Retention socket ensuring the cable is pulled back through the duct entry point. The pole will sit on a ledge near to ground level once lowered.
8. Rotate pole into correct alignment and tighten 2no 24mm setscrews in retention socket.
9. Place round pedestrian plug inside the side chamber of socket and close rectangular side chamber cover.

